


FR9-1999-0082-US1

HERICOURT  
1/9



FR9-1999-0082-US1

HERICOURT  
2/9




FIG. 2




FIG. 3

FR9-1999-0082-US1

HERICOURT  
4/9




FIG. 4





FIG. 5

Socks Traffic Configuration Table  
(601)



Socks Server TOS Configuration Table  
(606)




FIG. 6




FIG. 7




FIG. 8




FIG. 9

FR9-1999-0082-US1

HERICOURT  
1/9




FIG. 1

FR9-1999-0082-US1

HERICOURT  
2/9




FIG. 2




FIG. 3

FR9-1999-0082-US1

HERICOURT  
4/9




FIG. 4





FIG. 5

Socks Traffic Configuration Table  
(601)



Socks Server TOS Configuration Table  
(606)




FIG. 6




FIG. 7




FIG. 8




FIG. 9